


NoiseDist

syn AFE

Noise [e]

- Assembly
- systemTest-Liv

200
180
160
140
120
100
80
60
40
20
0




NoiseDist

lin AFE

Noise [e]

- Assembly
- systemTest-Liv



NoiseDist

diff AFE

- Assembly
- systemTest-Liv

Noise [e]

120
100
80
60
40
20
0

